

Accessory and replacement parts for all POWR UPS products are available from the factory.
For information regarding items other than those listed, please contact POWR UPS.

PART NUMBER	DESCRIPTION	CONTROL
IDE-20CAB-20CC	Ribbon cable	100, 110
PSB4KB08SNNNN	8-pin connector	100, 110, 1000, 1100
PSB4KB10SNNNN	10-pin connector	100, 110, 1000, 1100
MDA-5	5 Amp, 250 V fuse	100, 110, 2748
MDA-15	15 Amp, 250 V fuse	1000, 1100, 2745, 2746, 2747
SC-60	60 Amp, 300 V fuse	2745-3, 2745-5
2745-05	Perforated cover	2745, 2748
2746-06	Perforated cover	2746
2747-06	Perforated cover	2747
31VC305	External 5K Speed Pot	2747
2745-06	Accel/Decel Module	2745, 2748
15137-04	Auxiliary transformer connector	2745
6DTB-07-000-L	Terminal block	2745, 2748
2MDV-15	Signal terminal block	2745, 2748
09-74-1031	Male connector	2746, 2747
09-50-3031	Terminal housing	2746, 2747
08-50-0106	Crimp Terminal	2746, 2747

AUXILIARY TRANSFORMERS

T90.25	90 V	250	VA	2745, 2749
T90.50	90 V	500	VA	2745, 2749
T90.01	90 V	1	KVA	2745, 2749
T90.02	90 V	2	KVA	2745, 2749
T130.50	130 V	500	VA	2745, 2749
T180.50	180 V	500	VA	2745, 2749
T180.01	180 V	1	KVA	2745, 2749
T180.02	180 V	2	KVA	2745, 2749
T48.50	48 V	500	VA	2745, 2749
T24.50	24 V	500	VA	2745, 2749
T24.01	24 V	1	KVA	2745, 2749
T12.25/46,47	12 V	250	VA	2746, 2747
T24.25/46,47	24 V	250	VA	2746, 2747
T24.50/46,47	24 V	500	VA	2746, 2747
T24.01/46,47	24 V	1	KVA	2746, 2747
T48.50/46,47	48 V	500	VA	2746, 2747
T130.50/46,47	130 V	500	VA	2746, 2747